

Front Row Juno Voice Commands

****all commands are issued while pressing button on teacher microphone; wait for green screen on tower and audible signal ****

- **“increase”** turns the volume of the tower up 2 decibel points. This unit is direct line of sight, so you must be facing it. Very handy to be able to control volume from across the room.
- **“reduce”** turns the volume down 2 decibels.
- **“LCD”** locks the screen so that students can't change the volume on the LCD screen while you are away from the classroom.

This unit also has **“Lesson Capture”** for future use
****division office IT approval to run software may be required**:**

- Front Row will provide a software licence number. Lesson Capture is downloadable from the Front Row website; put in the number and assign a teacher blog website or school website where you want your lessons to end up.
- When teaching a new concept or new Math or language lesson, press the same button on your teacher mic and say **“Begin”**
- Teach your lesson; say **“Suspend”** if you have to pause the lesson.
- When finished, say **“Finish”**
- When the recording is finished, it will automatically upload the lesson to the website you designated when you ran the software.
- Students are then given the website address to later retrieve the lesson or practice repeating language skills.